

Building & Technology Supplies, LLC

Logistics and Sales of Construction/Industrial Products - Export

Corporate Remit: P.O. Box 450852, Sunrise, FL 33345

Phone:954-839-7403/ 954-656-1266

LINE	STYLE	COLOR	BK	STYLE NAME & SIZE	PRICE
CARPET TILES 24 X24				6.67 SY/BX	\$26.86PER YD
STYLE : STREET LIFE					
001	03973	36101	PC	STREET LIFE 24 X24 PRODUCT NO.: 6298190016 / LIGHTS OUT / PIECE / TILE BRAND.: TANDUS	
002	03973	36103	PC	STREET LIFE 24 X 24 PRODUCT NO.: 6298190018 / MASS TRANSIT / PIECE / TILE BRAND.: TANDUS	
003	03973	36104	PC	STREET LIFE 24 X 24 PRODUCT NO.: 6298190019 / STREET CORNER / PIECE / TILE BRAND.: TANDUS	
004	03973	36106	PC	STREET LIFE 24 X 24 PRODUCT NO.: 6298190021 / HIGH LINE / PIECE / TILE BRAND.: TANDUS	
005	03973	36107	PC	STREET LIFE 24 X 24 PRODUCT NO.: 6298190022 / PIER 40 / PIECE / TILE BRAND.: TANDUS	
006	03973	36110	PC	STREET LIFE 24 X24 PRODUCT NO.: 6298190025 / BIKE PATH / PIECE / TILE BRAND.: TANDUS	
007	03973	36111	PC	STREET LIFE 24 X 24 PRODUCT NO.: 6298190026 / CHINATOWN / PIECE / TILE BRAND.: TANDUS	
008	CEx ADHESIVE PAIL-SPREAD 133-155YD-				\$110.00 PER PAIL
Form #002-A					
ER3® MODULAR NON-RS INSTALLATION & FLOOR PREPARATION INSTRUCTIONS					
General Notes					
These installation instructions are general and are not intended to be applicable for all sub-floor conditions. If you have any questions concerning the proper installation (or use) of any of our manufacturers products, please contact BTS at 954-839-7403. All products should be inspected for dye lot, style, color, size, quality and shipping damage prior to installation and should not be installed if any irregularities are observed. It is solely the responsibility of the installation contractor to insure that the sub-floor is properly prepared prior to installation.					
Installer Certification					
Our manufacturer requires that all installers be certified prior to performing the installation of modular products on actual jobsites. Contact your representative for more information on installer certification.					
Site Requirements					
Our manufacturer's modular products are intended for indoor installations on dry, properly prepared sub-floors. The product is not intended for installation on walls, stairs, ramps, outdoors, or on wet surfaces. Our manufacturer is not responsible for product failure of any kind if these floor preparation and installation instructions are not adhered to. Only installation materials approved by our manufacturer should be used. Be certain to read and adhere to the shelf life and freeze-thaw stability information that is printed on the label of the installation materials.					
Moisture & pH					
Excessive moisture and/or high pH on any sub-floor, especially concrete, can cause product failure. For ER3 Modular product, the maximum					

Building & Technology Supplies, LLC

Logistics and Sales of Construction/Industrial Products - Export

Corporate Remit: P.O. Box 450852, Sunrise, FL 33345

Phone: 954-839-7403 / 954-656-1266

allowable moisture vapor emission rate (MVER) from the sub-floor is 5.0 pounds, as tested according to ASTM F-1869-04 (Std. Test method for measuring Moisture Emission Rate of Concrete). The required pH range is 9.0 or less as tested according to ASTM F-710-05. The In-Situ/RH (relative humidity) requirement on concrete is not to exceed 80% as tested according to ASTM F-2170-02 (Std. Test method for measuring Relative Humidity in Concrete). When using ER3 modular, our manufacturer requires that at least 1 MVER and 2 RH tests be performed on the initial 1000 sq ft of each project. In addition, a minimum of one test, alternating between MVER and RH, per 1000 sq ft is required for the balance of the project. **When In-Situ RH testing has been eliminated from the test protocol, the Maximum Allowable MVER will revert to 3 lbs/24hr/1,000 sq ft.** Refer to our Technical Services Bulletin "Moisture and pH Testing of our manufacturer's Products" for specific instructions on test methods, ambient conditions, and other requirements.

Note that moisture vapor emission testing, relative humidity, and pH testing indicate the moisture level and pH of the concrete sub-floor at the time of installation. These tests do not provide static results and both moisture and pH can increase over time. Our manufacturer is not responsible for product failure as a result of changes to sub floor conditions, including increases in moisture or pH levels, post installation. Experience has shown that more accurate and representative MVER, RH and pH testing results can be achieved when the HVAC system is functioning 24/7 for two weeks prior to installation and the indoor air quality has acclimated to occupancy conditions. In cases where the flooring substrate is light weight concrete, or is a Gypsum based leveling compound used as a topcoat over existing concrete, MVER results are not an accurate means of evaluating the conditions of the flooring substrate; therefore, RH will be the only recognized moisture test method.

PH Testing

Preparing the surface of a concrete slab for pH testing requires the following attention to detail. Make sure the concrete surface is adequately cleaned of any adhesives, primers, curing compounds, surface contaminants, etc. Exercise care not to over clean the surface of the concrete removing the thin layer of carbonation. This can result in higher, non-responsive pH readings. Slightly wet the concrete sub-floor surface with a small amount of distilled water and allow the water to stand for one minute. Apply pH test paper to the wet concrete surface and allow the pH test paper to remain in contact with the wet area for one minute. The pH test paper will change color depending on the pH of the wetted surface and a color scale is provided with the pH test papers for comparison. Note pH test paper commonly supplied in MVER test kits only measures up to a pH of 12 accurately.

Installation of our manufacturer's products on sub-floor conditions that exceed the specifications and limitations provided in this document will void the applicable limited warranties. The manufacturer does not represent or make any express or implied warranties that the products will or will not affect, prevent or cure any other moisture or alkalinity-related issues that may arise because of the moisture and alkalinity levels found in the concrete. Our manufacturer expressly disclaims such express or implied representations or warranties.

Temperature & Humidity

The temperature of the interior environment, including the sub floor should be no lower than 65°F and no higher than 90°F at least 72 hours prior to, during and after the tile installation. All of our manufacturer's products and installation materials should be stored between 65°F and 90°F for at least 48 hours prior

to installation. Relative humidity should be no more than 65%.

Floor Inspection

The sub-floor must be structurally sound and dry prior to installation. Any curing chemicals, sealers, finishers or other chemical treatments used on sub floors must be chemically and physically compatible with the our manufacturer backing and adhesive systems, or they must be removed or skim coated with a Portland cement based product. Chemically abated floors or the use of chemical adhesive removers prior to the application of the backing and adhesive systems can result in product or installation failures and are not recommended nor warranted. If you have questions concerning the compatibility of specific chemicals with our manufacturer backing and adhesive systems, please contact BTS at 954-839-7403 / 954-656-1266

Floor Debris Cleaning

Clean the sub-floor of all excess concrete spots, solid debris or paint spots using suitable scraping methods. Completely remove all wax, dirt, grease, paints or old adhesives (especially cutback or emulsion). DO NOT use solvents or any other chemical adhesive removers to clean the sub-floor. DO NOT use oil-based or silicone based sweeping compound. Contact BTS for specific floor preparation guidelines including installation over cutback or information on general purpose adhesive.

Floor Patching and Leveling

All sub-floors should be level. Concrete sub-floors should be troweled smooth and should conform to the standard specifications as recommended by the Portland Cement Association. The floor should be flat to within 1/8" in 10 feet. Cracks, holes and depressions can be filled using Portland Cement/Latex fortified patching material. Do not install over loose tile (VAT, VCT or others loose existing flooring substrates).

Floor Cleaning

Sweep and vacuum the floor after patching and debris removal. Do not use oil, wax, or silicone based sweeping compound. Make sure all perimeter areas are clean. Smooth, nonporous floors should be damp mopped prior to product installation.

Floor Priming (General)

All porous, gritty, chalky and dusty surfaces should be primed using our manufacturer's C-36E* Floor Primer. All patched areas must be fully primed. Primer can be applied using a paint roller. Allow the primer to dry completely. Primer turns light blue and will not transfer to the touch

Building & Technology Supplies, LLC

Logistics and Sales of Construction/Industrial Products - Export

Corporate Remit: P.O. Box 450852, Sunrise, FL 33345

Phone: 954-839-7403 / 954-656-1266

when dry.

Surfaces that are nonporous do not require primer. These surfaces must be cleaned as noted above.

When old adhesives, other than cutback or emulsion adhesives, have been removed, use our manufacturer's C-56* Premium Floor Primer. This is not a substitute for removal of old adhesive and proper floor debris cleaning, but a safeguard for problems caused by small amounts of old residual adhesive.

Where existing, non-asbestos containing cutback adhesive is present, remove the old cutback to the substrate. A licensed asbestos contractor in accordance with state and federal requirements should perform removal of asbestos containing cutback adhesive. After removal of the cutback adhesive, prime the sub-floor using our manufacturer's C-56 Premium Floor Primer which is only intended to cover small amounts of old cutback adhesives that may interfere with adhesion of the new floor covering. After the floor has dried completely, install the non-RS modular tiles following installation procedures.

Installation

Determine the lay direction of the carpet based on building design and installation efficiencies.

1) Locate the first centerline in the installation area by marking the center point of two opposing, parallel walls. Snap a white (not blue or red) chalk line between the two center marks. Snap a second, perpendicular chalk line at the mid-point of this line (use a 3-4-5-triangle method to make sure the second line is perpendicular to the first. **This procedure is very important.**

2) Check the distance from each centerline to its parallel wall and determine how many tiles will be required. Shift the line as needed (in a parallel direction) to balance the width of the border tiles (tiles against the wall). Border tiles where possible should not be less than half-tile widths.

3) Our Manufacturer's C-14E or C-EX* Pressure Sensitive Adhesive must be used in a full spread mode to install ER3 Modular. Apply C-14E or C-EX* with a short nap paint roller. Do not allow the wet adhesive to puddle. Allow the adhesive to set prior to installing tiles. C-14E or C-EX* are set when they dry clear and will not transfer to the hand when touched. Tiles should be installed immediately after the adhesive has dried. The adhesive **MUST BE DRY** prior to installing ER3 Modular. **DO NOT apply adhesive over flat cable. *Primer should not be used with C-EX Adhesive. The bond of the C-EX to the clean concrete is stronger than the bond to the primed concrete.**

4) Directional arrows are printed on the back of all tiles. Determine the "arrow direction" for the installation and make sure all tiles are installed in the same direction (unless a quarter-turn or other installation pattern is required).

5) Start from the intersection point in the center of the floor and install the first line of tiles along the first centerline. Install the second line of tiles along the perpendicular centerline. Keep all the tiles exactly on the chalk lines. Fit the tiles snugly next to each other by sliding them into place. **DO NOT FORCE THE TILES. DO NOT TRAP FACE YARN BETWEEN OR UNDER TILE EDGES.** Press the tiles into place. When the tiles are properly positioned roll with a 75 to 100 lb roller to assure a positive contact between the tile backing and the application of C-14E adhesive. Tiles can be removed from the floor at any time for realignment.

6) Continue to install the tiles in a stair-step or pyramid pattern starting from the intersection point. Check to make sure the tiles are properly aligned at the edges during installation.

7) Install border tiles by placing a tile face down exactly on top of the last full line of field tile, keep the arrows pointed in the same direction. This is the *cut tile*. Take another full tile and butt it against the wall allowing it to fall on top of the cut tile. This is the *reference tile*. Score a line on the back of the *cut tile* using the edge of the *reference tile* as a guide. Cut the *cut tile* along the reference line. Do not cut through to the field tile. Install the *cut tile* with the cut edge along the wall. Doorways and other permanent objects can be fitted using this method, by making a pattern or by measuring techniques. Provide transition strips on all exposed tile edges.

8) When installing over raised access flooring systems the starting installation grid should always overlap the access panel joints. Installing the modular carpet tiles so that they are flush with the panels will create more visible tile seams, and if there is any movement in the panels due to not being securely in place the tile edges may be adversely affected.

8) When installing over raised access flooring systems the starting installation grid should always overlap the access panel joints. Installing the modular carpet tiles so that they are flush with the panels will create more visible tile seams, and if there is any movement in the panels due to not being securely in place the tile edges may be adversely affected.

Other

For installation over substrates not mentioned here, information on exposed edges, air pockets, repairs, more-detailed installation instructions, and/or other installation information, please contact BTS for more information

Building & Technology Supplies, LLC

Logistics and Sales of Construction/Industrial Products - Export

Corporate Remit: P.O. Box 450852, Sunrise, FL 33345

Phone: 954-839-7403 / 954-656-1266

